



CM1 Chime Module For the OS-2 or OS-2BOSE Interface

CM1 Installation Instructions:

Unplug the OS2-RAD cable from the interface prior to wiring the CM1.

1. Connect the CM1's BLACK wire to the OS2-RAD BLACK wire.
2. Connect the CM1's YELLOW wire to the OS2-RAD YELLOW wire
3. Insert the CM1's ORANGE wire with the MOLEX pin into pin location #12 of the OS2-RAD (18 pin) MOLEX plug.
Do not use force! Pin will snap in with minimal effort, if inserted correctly.
4. Plug the OS2-RAD plug back into the interface .
5. When first powered up, the CM1 will chime one time to indicate proper power connection. All warning chimes are now retained.

