



**SCOSCHE®**  
**CAR STEREO**

**HARNESS**

**CAMOSM**

2010-UP Camaro  
Onstar Module



Designed and Engineered in the U.S.A  
Custom Manufactured in China



### WIRE COLOR CODES

THE COLOR CODES USED ON THIS CAR STEREO CONNECTOR HARNESS CONFORM TO THE E.I.A. (ELECTRONICS INDUSTRY ASSOCIATION) STANDARD. THESE COLORS MAY DIFFER FROM THE WIRING CODES FOUND ON YOUR STEREO. ALWAYS REFER TO YOUR STEREO OWNERS MANUAL FOR SPECIFIC WIRING DETAILS BEFORE MAKING ANY CONNECTIONS.

YELLOW =	12 VOLT BATTERY/CONTANT
RED =	12 VOLT IGNITION / SWITCHED
BLACK =	CHASSIS GROUND
BLACK/WHITE =	FACTORY AMPLIFIER GROUND
BLUE =	POWER ANTENNA/FACTORY AMPLIFIER REMOTE TURN ON
BLUE/WHITE =	FACTORY AMPLIFIER REMOTE TURN ON
ORANGE =	ILLUMINATION / DIMMER
ORANGE/WHITE =	ILLUMINATION / DIMMER
ORANGE/BLACK =	ILLUMINATION GROUND / DIMMER GROUND
BROWN =	MUTE / NOT USED
WHITE =	LEFT FRONT POSITIVE (LF+)
WHITE/BLACK =	LEFT FRONT NEGATIVE (LF-)
GREY =	RIGHT FRONT POSITIVE (RF+)
GREY/BLACK =	RIGHT FRONT NEGATIVE (RF-)
GREEN =	LEFT REAR POSITIVE (LR+)
GREEN/BLACK =	LEFT REAR NEGATIVE (LR-)
VIOLET =	RIGHT REAR POSITIVE (RR+)
VIOLET/BLACK =	RIGHT REAR NEGATIVE (RR-)

### NOTES:

- CAP AND INSULATE ALL UNUSED WIRES INDIVIDUALLY TO PREVENT SHORT CIRCUITS.
- THIS WIRING HARNESS MAY NOT INCLUDE ALL WIRE COLORS LISTED ABOVE.
- IF THIS WIRING HARNESS CONTAINS WIRE COLORS THAT ARE NOT INDICATED IN THE LIST ABOVE, PLEASE CONTACT SCOSCHE TECHNICAL SUPPORT TOLL-FREE HOTLINE AT (800) 363-4490 EXT. 3 FOR FURTHER INSTRUCTION.

© 2016 SCOSCHE INDUSTRIES, INC.,  
Oxnard, California 93033

[www.scosche.com](http://www.scosche.com)

California Proposition 65 WARNING:  
This product contains a chemical(s) known to  
the State of California to cause cancer and  
birth defects and other reproductive harm.



Technical Support: (800) 363-4490 x3







**SCOSCHE™**

**CAMOSM**

**2010-UP CHEVROLET CAMARO  
ONSTAR INTERFACE MODULE**

MADE IN CHINA - FABRIQUÉ EN CHINE

**Tech Support:**

**800-621-3695 ext.3**

**[www.scosche.com](http://www.scosche.com)**





ONSTAR MODULE MUST BE  
CONNECTED BEFORE CONNECTING  
HVAC CONTROLLER



ONSTAR MODULE MUST BE  
CONNECTED BEFORE CONNECTING  
HVAC CONTROLLER



