



PRODUCT FEATURES:

- Adds Bluetooth Music streaming to the OEM Radios that are equipped with Factory XM Tuner.
- Maintains the use of the factory XM radio.
- Automatically pauses BT Streaming when a call is received, and resumes when the call is ended.
- Easy installation at the XM tuner location. No need to remove the radio.
- Hear Navigation App voice prompts from the factory speakers.
- Magnetic Phone Mount Included.

NOTES:


1. Vehicle must have a factory XM Tuner.
2. Radio must be in Bluetooth mode in order to hear Navigation app voice prompts.
3. The BTS-GM1X will shut down unless a device is paired within 10 minutes. To turn the module back on, press AM or FM then the XM button or press and hold the SEEK DOWN button.
4. Handsfree feature is not available. Use the phone to make and receive phone calls.

INSTALLATION INSTRUCTIONS:


Below is a sample installation of the BTS-XM1 on a GMC Denali. The XM tuner is behind the glove box. Other vehicles may have the XM tuner at a different location such as in the trunk or on some SUVs, the rear panel where the tire jack is located. For a list of XM tuner locations, please see page 3.



1. Open the glove box and push up on the locking tab to release the glove box.



2. Locate the factory XM tuner.



3. Unplug the factory 16-pin XM tuner connector and plug it into the 16-pin mating connector of the BTS-GM1X harness.



4. Plug the other 16-pin connector of the BTS-GM1X harness to the XM tuner.



5. Plug the 12-pin Molex connector to the BTS-GM1X module.



6. Use cable ties to secure the module.





7. Go to the Bluetooth setting on your phone and connect to blueLOGIC.



8. Go to XM mode on the radio and press SEEK DOWN until you hear a beep. Confirm that blueLOGIC is shown on the screen. Play music from your phone and the audio will be heard from the factory speakers.




9. Press the SEEK DOWN button until you hear a beep to toggle between XM and Bluetooth A2DP mode. If the music is paused, press the RIGHT ARROW button on the screen. See Note below.

NOTE: On some Cadillac models, press the PRESET DOWN button to toggle between XM and Bluetooth A2DP instead of the Seek Down button.



MAGNETIC PHONE MOUNT ASSEMBLY AND USE:

1. Pop-in magnetic head to base socket.
2. Tighten locking nut to desired tilt.
3. Slide into the AC vent grille.
4. Use the desired metal plate size and stick on the back of the phone or insert behind the phone case.



VEHICLE APPLICATIONS:

BUICK

2008-2012 Enclave
2008-2011 Lucerne

CADILLAC

2006-2011 DTS
2007-2013 Escalade
2007-2009 SRX

GMC

2007-2013 Acadia
2008-2011 Savana
2007-2013 Sierra
2007-2013 Yukon

CHEVROLET

2007-2013 Avalanche
2007-2008 Equinox
2009-2011 Express Van
2006-2013 Impala
2006-2007 Monte Carlo
2007-2013 Silverado
2007-2013 Suburban
2007-2013 Tahoe
2009-2012 Traverse

HUMMER

2008-2009 H2

PONTIAC

2007-2009 Torrent

SAAB

2008-2009 9-3
2007-2009 9-5

SATURN

2007-2009 Outlook
2008-2009 Vue



APPLICATION**TUNER LOCATION****BUICK**

2008-2012 Enclave Cargo Area - Behind Left Rear Quarter Panel Trim
2008-2011 Lucerne Trunk - Behind Left Rear Quarter Panel Trim

CADILLAC

2006-2011 DTS Trunk - Behind Left Rear Quarter Panel Trim
2007-2013 Escalade Behind Glove Box as shown in instructions
2007-2009 SRX *EXTENSIVE Disassembly Required* Cargo Area - Behind Right Rear Quarter Panel Trim

CHEVROLET

2007-2013 Avalanche Behind Glove Box as shown in instructions
2007-2008 Equinox Cargo Area - Behind Left Rear Quarter Panel Trim
2009-2011 Express Van Behind Drivers side Steering Column Knee Panel
2006-2013 Impala Trunk - Behind Right Rear Quarter Panel Trim
2006-2007 Monte Carlo Trunk - Behind Right Rear Quarter Panel Trim
2007-2013 Silverado Behind Glove Box as shown in instructions
2007-2013 Suburban Behind Glove Box as shown in instructions
2007-2013 Tahoe Behind Glove Box as shown in instructions
2009-2012 Traverse Cargo Area - Behind Left Rear Quarter Panel Trim

GMC

2007-2013 Acadia Behind the Lift Gate Motor
2008-2011 Savana Behind Drivers Side Steering Column Knee Panel
2007-2013 Sierra Behind Glove Box as shown in instructions
2007-2013 Yukon Behind Glove Box as shown in instructions

HUMMER

2008-2009 H2 Behind Glove Box as shown in instructions

PONTIAC

2007-2009 Torrent Cargo Area - Behind Left Rear Quarter Panel Trim

SAAB

2008-2009 9-3 Cargo Area - Behind Right Rear Quarter Panel Trim
2007-2009 9-5 Cargo Area - Behind Right Rear Quarter Panel Trim

SATURN

2007-2009 Outlook Cargo Area - Behind Left Rear Quarter Panel Trim
2008-2009 Vue Cargo Area - Behind Left Rear Quarter Panel Trim

