

# Malibu Slider Bimini Pole Modification Guide

## 1) Original stock pole and modified pole visual comparison



## 2) Disassemble the arm and place the pole in vice and cut with pipe cutter just below first hole (1 7/8")



## 3) Clean out sharp burs and edges from the cutting process so inner pole will slide without scaring



4) New hole should be same distance as the factory spacing. Get close and mark with sharpie



5) Use a punch and tap a starter point for the drill bit. Drill new hole with a 9/32 drill bit.



6) Clean sharp edges from newly drilled hole



7) File out inside to remove sharp metal debris from inside pole

