

KIT CONTENTS

ITEM	QTY	DESCRIPTION
1	1	CONTROL MODULE
2	1	SWITCH
3	1	MICROPHONE
4	1	AUDIO/POWER HARNESS
5	1	WIRE TIES
6	1	2.25" X 2.25" VELCRO
7	1	.75" X .50" DOUBLE SIDED TAPE
8	1	FOAM TAPE
9	1	CONVOLUTED TUBING
10	1	OPERATION INSTRUCTIONS



HARDWARE BAG CONTENTS

ITEM	QTY	DESCRIPTION

ADDITIONAL ITEMS REQUIRED FOR INSTALL

ITEM	QTY	DESCRIPTION

CONFLICTS

--

RECOMMENDED TOOLS

PERSONAL & VEHICLE PROTECTION	
SAFETY GLASSES	
FENDER COVER	
GLOVES (OPTIONAL)	
SPECIAL TOOLS	
BATTERY POST PROTECTOR	
INSTALLATION TOOLS	
TRIM REMOVAL TOOL	
PHILIPS SCREWDRIVER	
10MM SOCKET	
3/4" DRIVE WRENCH	
SPECIAL CHEMICALS	

GENERAL APPLICABILITY

09 FIT
09 CIVIC COUPE, HYBRID, EX
09 PILOT

SERVICE PARTS

ITEM	PART#	DESCRIPTION
	250-7505	SWITCH
	250-7507	CONTROL MODULE
	250-7508	MICROPHONE ASSEMBLY

LEGEND

	STOP: DAMAGE TO VEHICLE MAY OCCUR. DO NOT PROCEED UNTIL PROCESS COMPLIANCE HAS BEEN MET.
	OPERATOR SAFETY: USE CAUTION TO AVOID RISK OF INJURY.
	CRITICAL PROCESS: PROCEED WITH CAUTION TO ENSURE A QUALITY INSTALLATION. THESE POINTS WILL BE AUDITED ON A COMPLETED VEHICLE INSTALLATION.
	GENERAL PROCESS: THIS HIGHLIGHTS SPECIFIC PROCESSES TO ENSURE A QUALITY INSTALLATION. THESE POINTS WILL BE AUDITED DURING THE ACCESSORY INSTALLATION.
	TOOLS & EQUIPMENT: THIS CALLS OUT THE SPECIFIC TOOLS AND EQUIPMENT REQUIRED FOR THE PROCESS.
	REVISION MARK: THIS MARK HIGHLIGHTS A CHANGE IN INSTALLATION WITH RESPECT TO PREVIOUS ISSUE.
	VEHICLE PROTECTION: THIS CALLS OUT FOR PROTECTION OF VEHICLE REQUIRED FOR THIS PROCESS.

SPECIAL NOTE: INSTALLATION SEQUENCES
 AFTER SAFETY MANDATED PREPARATORY STEPS HAVE BEEN TAKEN, THE INSTALLATION SEQUENCE IS THE SUGGESTED METHOD FOR COMPLETING THE ACCESSORY INSTALLATION. IN SOME INSTANCES THE SUGGESTED SEQUENCE IS WRITTEN FOR ONE ASSOCIATE TO INSTALL AND IN OTHERS THE SEQUENCE IS GIVEN AS PART OF A TEAM ACCESSORY INSTALLATION. UNLESS OTHERWISE STATED IN THE DOCUMENT, THE ASSOCIATES MAY PERFORM THE INSTALLATION STEPS IN ANY ORDER TO MAKE THE INSTALLATION AS EFFICIENT AS POSSIBLE WHILE MAINTAINING CONSISTENT QUALITY.

INSTALLATION



CAUTION: IT IS ADVISABLE TO DISCONNECT THE NEGATIVE BATTERY CABLE FOR 90 SECONDS BEFORE BEGINNING INSTALLATION TO AVOID UNINTENDED AIR BAG DEPLOYMENT FAILURE TO HEAD THIS WARNING MAY RESULT IN AIRBAG DISCHARGE AND MAY CAUSE SERIOUS INJURY OR DEATH.
FIGURE 1




FIGURE 1

FIT PREPARATION:



1. REMOVE THE LOWER FINISH PANEL COVER ABOVE THE SHIFT LEVER BY USING A TRIM TOOL. **FIGURE 2**




FIGURE 2

2. SLIDE THE VENT LEVER TO THE RIGHT. REMOVE SCREW TO RELEASE THE RADIO ASSEMBLY FROM THE MOUNTING BRACKET. THE SCREW CAN BE LOCATED BY LOOKING THROUGH THE GLOVE BOX OPENING. **FIGURE 3**





FIGURE 3


FIT PREPARATION: CONTINUED...




3. APPLY MASKING TAPE TO THE FINISH PANEL AS SHOWN.
OPEN THE PASSENGER SIDE DASH BIN ABOVE THE GLOVE BOX. CAREFULLY REMOVE THE RADIO ASSEMBLY BY INSERTING A TRIM TOOL IN THE FINISH PANEL INSERT LOCATION INSIDE THE BIN. DISENGAGE THE CLIPS. DISCONNECT ALL CONNECTORS FROM THE RADIO ASSEMBLY. **FIGURE 4**



4. REMOVE THE LOWER FINISH PANEL BELOW THE STEERING WHEEL. **FIGURE 5**



5. PRESS IN TABS TO REMOVE THE SWITCH BLANK PLUG IN THE LOWER DASH FINISH PANEL. **FIGURE 6**




INSTALLATION


CIVIC PREPARATION:




1. DISENGAGE THE CLIPS TO REMOVE THE LOWER DASH FINISH PANEL BELOW THE STEERING WHEEL. **FIGURE 1**




2. REMOVE THE PHILLIPS SCREW AND DISENGAGE THE CLIPS TO REMOVE THE INSTRUMENT CLUSTER FINISH PANEL. **FIGURE 2**




3. REMOVE THE LOWER FINISH PANEL ABOVE THE SHIFT LEVER BY USING A TRIM TOOL. **REMOVE (2) 8MM SCREWS TO FREE THE RADIO ASSEMBLY FROM THE MOUNTING BRACKET.** **FIGURE 3**



4. CAREFULLY REMOVE THE RADIO ASSEMBLY BY USING A TRIM TOOL TO DISENGAGE THE CLIPS. DISCONNECT ALL CONNECTORS FROM THE RADIO ASSEMBLY. **FIGURE 4**



5. PRESS IN TABS TO REMOVE THE SWITCH BLANK PLUG FROM THE LOWER DASH FINISH PANEL. **FIGURE 5**



INSTALLATION




INSIGHT PREPARATION:



1. DISENGAGE THE CLIPS TO REMOVE THE LOWER FINISH PANEL COMPARTMENT ABOVE THE SHIFT LEVER BY USING A TRIM TOOL. DISCONNECT CONNECTOR. **FIGURE 1**

2. REMOVE THE GLOVE BOX. **REMOVE SCREW TO RELEASE THE RADIO ASSEMBLY FROM THE MOUNTING BRACKET.** USE THE HANDLE END OF A HAMMER IN BETWEEN THE BACK OF THE RADIO ASSEMBLY AND THE METAL BRACKET AND PUSH TO DISENGAGE THE CLIPS. CAREFULLY REMOVE THE RADIO ASSEMBLY AND DISCONNECT ALL CONNECTORS. **FIGURE 2**

3. REMOVE THE LOWER FINISH PANEL BELOW STEERING WHEEL. PRESS IN TABS TO REMOVE THE SWITCH BLANK PLUG. **FIGURE 3**




INSTALLATION


PILOT PREPARATION:




1. DISENGAGE THE CLIPS TO REMOVE THE LEFT AND RIGHT RADIO FINISH PANELS. **FIGURE 1**




2. REMOVE (2) PHILLIPS SCREWS AND DISENGAGE CLIPS TO REMOVE THE COMPARTMENT BELOW THE RADIO. **FIGURE 2**



3. REMOVE (4) PHILLIPS SCREWS AND CAREFULLY REMOVE THE RADIO ASSEMBLY. DISCONNECT ALL CONNECTORS. **FIGURE 3**



4. DISENGAGE THE CLIPS TO REMOVE THE LOWER FINISH PANEL BELOW THE STEERING WHEEL. **FIGURE 4**



5. PRESS IN TABS TO REMOVE THE SWITCH BLANK PLUG FROM THE LOWER FINISH PANEL. **FIGURE 5**




INSTALLATION

MICROPHONE



1. ROUTE THE MICROPHONE HARNESS TO AN AREA ON OR NEAR THE DASHBOARD AWAY FROM SIDE AIRBAGS OR VENTS. USE THE VEHICLE WIRING CLIPS AND SUPPLIED WIRE TIES TO SECURE HARNESES. USING THE DOUBLE SIDED TAPE, PLACE THE MICROPHONE IN THE SELECTED AREA AS SHOWN IN **FIGURE 1**.



CONTROL SWITCH



1. INSERT THE CONTROL SWITCH INTO THE REMOVED SWITCH BLANK FINISH PANEL. **THE SOLID TRIANGLE SHOULD BE AT THE TOP OF THE SWITCH.** FIGURES 2-5. ROUTE THE SWITCH HARNESS ALONG THE EXISTING VEHICLE WIRING BEHIND THE DASHBOARD TO THE CENTER CONSOLE AREA. SECURE HARNESES WITH WIRE TIES.



INTERFACE MODULE



1. CONNECT ALL HARNESSES TO THE INTERFACE MODULE.
FIGURE 6.

2. MOUNT THE INTERFACE MODULE NEAR THE JUNCTION BOX OR BEHIND THE CENTER CONSOLE. USE WIRES TIES TO SECURE THE MODULE AS SHOWN IN **FIGURE 7.**

AUDIO/POWER HARNESS



1. PRESS IN GRAY TAB OR PRESS IN AND PULL WHITE TAB TO REMOVE CONNECTOR FROM THE RADIO ASSEMBLY AS SHOWN IN **FIGURES 8.**

2. CONNECT THE POWER/AUDIO HARNESS TO THE RADIO ASSEMBLY. CONNECT THE RADIO ASSEMBLY HARNESS SIDE TO THE MATING CONNECTORS ON THE POWER/AUDIO HARNESS. SECURE HARNESSES WITH WIRE TIES. **FIGURES 9-10.**

REASSEMBLY



1. RECONNECT NEGATIVE BATTERY CABLE AND TORQUE TO **36 IN*LBS.**
2. REINSTALL ALL TRIM PIECES TAKING SPECIAL CARE TO ENSURE HARNESSES AND WIRE CONNECTIONS ARE PROPERLY SECURED.
3. BE SURE HARNESSES IS NOT PINCHED OR BOUND BY TRIM PIECES.
4. BE SURE TO RECONNECT HOOD RELEASE CABLE.



FIGURE 6




FIGURE 7




FIGURE 8




FIGURE 9




FIGURE 10